ranklin<sup>®</sup> DBE-1470

Spanish <> English Dictionary

User's Guide www.franklin.com

## **License Agreement**

READ THIS LICENSE AGREEMENT BEFORE USING THE ELECTRONIC REFERENCE. YOUR USE OF THE ELECTRONIC REFERENCE DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE ELECTRONIC REFERENCE AND YOUR PURCHASE PRICE WILL BE REFUNDED. ELECTRONIC REFERENCE means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

Limited Use License

All rights in the ELECTRONIC REFERENCE remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use this ELECTRONIC REFERENCE. You may not make any copies of the ELECTRONIC REFERENCE or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the ELECTRONIC REFERENCE. You may not export or reexport, directly or indirectly, the ELECTRONIC REFERENCE without compliance with appropriate governmental regulations. The ELECTRONIC REFERENCE contains Franklin's confidential and proprietary information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

## Key Guide

## Dictionary Keys<sup>†</sup>

**CONJ** Conjugates a word.

**LANG** Toggles the entry language

between Spanish and

English.

**DICT** Goes to the dictionary. **LEARN** Goes to the Learning

Exercises menu.

GAMES Goes to the Games menu.

Organizer Keys<sup>†</sup>

**CLOCK** Goes to the clock.

**DATA** Goes to the Databank menu.

CALC Goes to the calculator.

CONV Goes to the metric converter.

**CURR** Goes to the currency

converter.

<sup>1</sup>Each unlabeled key at the top of the keyboard corresponds to the function displayed at the bottom of the screen directly above that key. Press the corresponding key to perform the function you want.

## **Function Keys**

 Turns the product on or off

Displays a help message.
When at an inflection
screen, displays Grammar
Guide section about the
inflection you were
viewing.

In the dictionary, goes to the Word Entry screen.
Clears the calculator. In the metric converter, goes to its main menu.

Backs up, erases a letter, or turns off the highlight at an entry.

Enters a word, selects an item, or begins a highlight in an entry.



Goes to the Organizer: clock, databank, calculator, metric converter and currency converter.



Displays the main menus for the dictionary.

?\*)

At the Word Entry screen, types a ? to stand for a letter in a word. At a menu, displays a menu item. At a dictionary entry, displays the headword. In games, reveals the word and forfeits the game.



Shifts to type capital letters and punctuation marks.



Shifts to allow **prev**, **next**, and to type a hyphen (-) or  $\tilde{n}$ .



Exits the book you were reading.

## Combination Keys\*

At a dictionary entry,

A or pages up or down.

At a dictionary entry, displays the previous or next entry.

Transfers a word between books.

Types a hyphen.

(₦) **+N** Types an *ñ*.

<sup>™</sup> **+M** Types an @.

+\_' Types an apostrophe.

+\_' Types a slash.

<sup>\*</sup>Hold the first key while pressing the second.



Goes to the travellers' phrases menu. If a word is in the Word Entry screen or is highlighted, finds any phrases containing that word.



At the Word Entry screen, types an asterisk to stand for a series of letters in a word. In games, gives a hint.

## Direction Keys



Move up or down (located on the side of the device).




Move left or right.



At menus and dictionary entries, pages down. At the Word Entry screen, types a space.

## Using the Special Features


Your unit is equipped with several special features that many, but not all BOOKMAN book cards use. To learn if you can use the special features with a particular book card, read its User's Guide.



On/Off: Turns the unit on and off. Function Keys: Each of these

unlabeled keys corresponds to the dictionary or organizer function that appears directly above it on the screen.

**Up/Down:** Scrolls up or down one line at a time, moves the highlight in the indicated direction, or moves between menu items.



Serial Port: Plug in a serial-to-USB or serial-to-serial cable here to connect this dictionary to your PC. Book Card Slot: The card slot is located on the back of the unit. It enables you to read electronic books

purchased from www.franklin.com and is compatible with all BOOKMAN and BMC cards.

**Battery Compartment:** The battery compartment is located on the back of the unit. It holds two AAA batteries.

## Replacing Batteries

Your product is powered by two AAA batteries. Follow these easy instructions to install or replace them. Please have the new batteries at hand before you remove the old ones.

- Turn your product off and turn it over.
- Lift the battery cover on the back of your product by pushing up on the catch.
- 3. Remove the old batteries.
- 4. Install the batteries following

## the +/- markings in the battery compartment.

#### Replace the battery cover.

Warning: If the batteries wear-out completely or if you take more than a few seconds while changing the batteries, any information that was entered in the built-in book or book card may be erased. You should always keep written copies of your important information.

## For Your Information

#### √ Follow the Arrows

The flashing arrows on the right of the screen show which arrow keys you can press to move around menus or view more text.

## √ Help is Always at Hand

You can view a help message at any screen by pressing **HELP**. Press (4) or (5) to read. To exit

help, press BACK.

#### ✓ About Screen Illustrations

Some screen illustrations in this User's Guide may differ slightly from what you see on screen. This does not mean that your unit is malfunctioning.

## Changing the Language

#### Message Language

When you turn on this product for the first time, choose the message language. Press A for English or press B for Spanish.

English: Press 😭

The message language is the language of prompts, help, and other messages. You can change the message language after your initial decision.

## **Entry Language**

The entry language is the language in which you enter words at the Word Entry screen. This determines which dictionary you will use, Spanish or English.

- 1. Press MENU.
- Use the direction keys to highlight [ESF], and then press ENTER to access the Spanishto-English dictionary.

Select x at the icon menu to go to the English-to-Spanish dictionary. Or you can press **LANG** at the Word Entry screen to switch between Spanish and English.

## Using the Main Menu

When you press **MENU**, you will see ten icons. Use these to quickly take you to different parts of your dictionary. Use the arrow keys to highlight the icon you want and press **ENTER**.



#### Understanding the Menu



Goes to the English-to-Spanish dictionary.



Goes to the Spanish-to-English dictionary.



Goes to the Learning Exercises menu.



Goes to the Games menu.



Goes to the English conjugation prompt.



Goes to the Spanish conjugation prompt.



Goes to the English travellers' phrases menu.



Goes to the Spanish travellers' phrases menu.



Goes to My Word List.



Goes to the Tools menu.

# Viewing a demonstration or tutorial

- 1. Press MENU.
- Use the arrow keys to highlight and press ENTER.
- Press 

   to highlight either Tutorial or View Demo and press ENTER.

To stop the demonstration or exit from the *Tutorial* and go to the Word Entry screen, press **CLEAR**.

To go to the main menu, press **MENU**.

When a book card is installed in your product, select *View Demo* from the Setup menu to see the demonstration for that card.

## Changing the Settings

When using this dictionary, you can activate the *Learn a Word* feature, adjust the screen contrast, the shutoff time, the type size, and the message language. The shutoff time is how long your product stays on if you forget to turn it off.

- 1. Press MENU.
- 2. Use the arrow keys to highlight and press ENTER.
- Settings will be highlighted. Press ENTER to select it.



- Press ♠ or ♥ to move ▶ to Learn a Word, Contrast, Shutoff, Type Size, or Mensajes (Message language).
- 5. Press **④** or **▶** to change the setting.

Your changes are automatically saved.

Press ENTER when done.Press CLEAR to return to the Word Entry screen.


#### ✓ Learn a New Word

Your dictionary comes with a *Learn* a *Word* feature to help you increase your Spanish or English vocabulary. Each time you turn your dictionary on, you can see a random headword.

## **Translating Words**

Your dictionary is fully bilingual. Try translating a Spanish word.

- Press LANG to change the entry language from English to Spanish, if needed.
- 2. Type a word (e.g., estudiar).




To erase a letter, press BACK.

Note: You do not need to type accents. To type accents, type the letter (e.g., e) and press ♠ repeatedly until the accent you want appears (e.g., é).

If you want to type an  $\tilde{n}$ , then hold

**FN** and press **N**. To type a capital, hold **CAP** and press a letter key. To type a number, hold **FN** and press **Q-P**. To type a hyphen, hold **FN** and press **J**.

3. Press ENTER to view the English translation.



Press **SPACE** or **▼** to scroll.

- 5. Press CLEAR when done.

To translate English words into Spanish, change the entry language from Spanish to English.

## ✓ Understanding Definitions

Dictionary entries consist of headwords, parts of speech, the translation, and/or definitions. Other forms of the word may follow the headword. After the translation or definition, you may see a list of usage examples.

- 1. Type saber.
- 2. Press ENTER.

#### ✓ Explanation of Genders

Spanish nouns are different than English nouns in that they must either be masculine or feminine. Each definition of a noun indicates which gender it is with m or f.

#### ✓ Misspelling Words

If you enter a misspelled word, a list of corrections appears. Highlight the word you want and then press **ENTER** to see its dictionary entry.

#### √ Choosing Multiple Forms

Some words in this dictionary have more than one form (e.g. si, si). When the word you are looking up has multiple forms, the different forms appear in a list.

Simply highlight the form you want and press **ENTER** to see its dictionary entry. For example, enter *si* at the Word Entry screen.



Highlight the form you want and press **ENTER** to see its dictionary entry. To go back to the Multiple Forms list, press **BACK**.

## **Highlighting Words**

Another way to look up words is by highlighting them in dictionary entries or word lists. You can then find their definitions, phrases, or add them to *My Word List*.

 At any text, press ENTER to start the highlight.

```
STITON, seffora n

1:gentleman m, man m, lady f,

woman f, wife f

2:Sir m, Madam f <estimados se-

ñores: Dear Sirs>

3:Mr. m, Mrs. f

4:lord m, lady f <el Señor: the

Lord>

COND LANG DICT LEARN GAMES
```

To turn the highlight off, press **BACK**.

Use the arrow keys to move the highlight to the word you want.

```
señor, señora /

1:gentleman /m, man /m, lady /,

woman /, wife /

2:Sir /m, Madam / (Estimatos) se-

ñores: Dear Sirs>

3: Mr. /m, Mrs. /

4: lord /m, lady / <el Señor: the

Lord>

CONJ LANG DIOT LEARN GAMES

To ... Press ...

define the word ENTER
```

find a phrase FN + ?\*
add word to My Word List LEARN

3. Press CLEAR when done.

## Finding Letters in Words

If you are uncertain about how to spell a word, type a question mark (?) in place of each unknown letter. To find prefixes, suffixes, and other parts of words, type an asterisk (\*) in a word. Each asterisk stands for a series of letters. **Note:** If you type an asterisk at the beginning of a word, it may take a little while to find the matching words.

- Press LANG to switch to the Spanish Word Entry screen, if needed.
- Type a word with ?s and \*s.To type an asterisk, hold down CAP and press ?.
- 3. Press ENTER.
- Press to move the highlight to the word you want and press ENTER to view its definition.
- 5. Press CLEAR when done.

## **Using Learning Exercises**

Using Learning Exercises, you can test your spelling, improve your vocabulary, browse the TOEFL® Test\* Word List, and get grammar guidance.

## Spelling Bee

1. Press LEARN.

Or you can press **MENU**, highlight and then press **ENTER**.

Highlight Spelling Bee and then press ENTER.

You can choose My Spelling Bee (English) which uses English words from My Word List, My Spelling Bee (Spanish) which uses

\*TOEFL is a registered trademark of Educational Testing Service (ETS). This product is not endorsed or approved by ETS. Spanish words from My Word List, or the TOEFL® Test Spelling Bee, which uses words from the TOEFL® Test Word List.

Select the list you want and press ENTER.

A word will flash on the screen for you to spell.

- Type in the word you just saw and press ENTER to see if you spelled it right.
- Press ENTER to see the definition of the word.
- 6. Press SPACE for a new word.
- 7. Press CLEAR when done.

## Flashcards

- 1. Press LEARN.
- Highlight Flashcards and then press ENTER.

You can choose My Flashcards (English) which uses English words from My Word List, My Flashcards (Spanish) which uses Spanish words from My Word List, or TOEFL® Test Flashcards which uses words from the TOEFL® Test Word List.

Select the list you want and press ENTER.

A word will appear on the screen for you to study or define. If needed, press **ENTER** to see the definition. Press **BACK** to return to *Flashcards*.

- 4. Press SPACE for a new word.
- 5. Press CLEAR when done.

#### TOEFL® Test Word List

- 1. Press LEARN.
- Highlight TOEFL® Test Word List and then press ENTER.

Press ② or ③ to scroll through the TOEFL® Test Word List. You can also type a letter to go to the first word beginning with that letter. For example, type **col** to highlight collaborate.

Press **ENTER** or **CONJ** at any word to view its definition or to conjugate it. Press **BACK** to return to the list.

## **Using The Grammar Guide**

Your dictionary includes a helpful grammar guide that describes parts of speech. You can view it by selecting from the main menu or by pressing LEARN.


#### From the Learning Exercises Menu

- 1. Press MENU.
- 2. Highlight and then press ENTER.

Or you can press **LEARN**.

Press 

 to highlight Grammar
 Guide and then press ENTER.



- Press 

   to highlight the topic you want to study and then press ENTER.
- Press SPACE or ▼ to read.
- 6. Press FN + **▶** or **④** to view the next or previous topic.

#### From an Inflection Screen

- 1. Press MENU, highlight (SWEEL) or (SPE), and then press ENTER.
- Type a word to conjugate, and then press CONJ.
- Press FN + (\*) or (\*) repeatedly to find the tense you want to read about in the Grammar Guide.

IMPERFECT
yo estudiaba
I studied, I was studying
tú estudiabas
you studied, you were studying
él estudiaba
he studied, he was studying
cony lang

#### 4. Press HELP.

Press • to view this help message.
The imperfect is used to describe something in the past that was ongoing or habitual ('Imperfect' here means 'unfinished'). Generally, the Spanish imperfect corresponds to the English past progressive and CONJ LANG DOCT LEARN GAMES

Information about the tense will be displayed along with usage examples.

Press BACK to return to the inflection screen or press CLEAR to return to the Word Entry screen.

## Using My Word List

You can save up to 40 words total, in both English and Spanish, in My Word List for personal study or review. My Word List is saved between sessions unless your product is reset.

#### Adding Words from the Learning Exercises Menu

- 1. From My Word List, press 🕒 or
  - to highlight Add a word and press ENTER.



2. Type a word.

- 3. Press ENTER to add the word.
- 4. Press CLEAR when done.

## Adding Words from the Word Entry Screen

You can also add words to My Word List directly from the Word Entry screen.

- 1. Press MENU.
- 2. Press LANG to choose the language of the word you want to add (e.g., *Spanish*).

English words will be added to the English List; Spanish words will be added to the Spanish List.

- 3. Type the word you want to add to your word list (e.g., elegante).
- 4. Press LEARN.



Your selection is included in the menu item.

- 5. Press ENTER to add the word.
- 6. Press CLEAR to return to the Word Entry screen.
  - ✓ Adding Highlighted Words

You can also add words to My Word List from definitions and correction lists. First highlight a word and then press **LEARN**. Add "your word" will be highlighted. Press **ENTER** to add the word.

## Viewing My Word List

- 1. Press MENU.
- 2. Highlight and then press ENTER.

Or you can press LEARN.

Press LANG to switch from the English to the Spanish List, if needed.

English list: Empty (or Spanish list: Empty) will be displayed if either is empty.

- English List (or Spanish List) will be highlighted. Press ENTER to view the list.
- 5. Highlight a word on the list.
- Press ENTER to view its definition(s) or press CONJ to view its inflections.

## Removing a Word from My Word List

- From My Word List, select Delete a Word and then highlight the word you want to delete.
- 2. Press ENTER to delete that word.

#### Erasing My Word List

- 1. From My Word List, select Erase the List.
- Press Y to erase the list or press N to cancel.

**Note**: When you erase one list, the other list is not erased.

## Advanced Verb Conjugations

Conjugations show inflections, or changes in a word's gender, tense, etc. This dictionary includes extensive inflections of nouns, verbs, modifiers, and other words.

#### From the Icon Menu

1. For example, press MENU, use the arrow keys to highlight [DOPN | DOPN | DOPN

To choose English conjugation, highlight [ SUPPL ]. You can also press CONJ and then LANG to choose the language.

- 2. Type a word (e.g., leer).
- Press CONJ.If needed, highlight the part of

speech or translation you want and press **ENTER**.

```
OUERVIEW
yo leo (today)
I read (today)
yo leeré (tomorrow)
I will read (tomorrow)
yo lei, yo leia (yesterday)
I read, I was reading (yesterday)
cony LANG DICT LEARN GAMES
```

These are the principal forms of the Spanish verb "leer". The English translations are below each Spanish inflection.

- Press SPACE or 

   to scroll.
   Press ? to display the root word.
- Press CONJ or hold FN and press preparedly to view more inflections.

If the word is a noun, an adjective, or another modifier, then there won't be any other inflections.

Press CLEAR when done.

#### From a Dictionary Entry

Some words have different parts of speech or multiple translations. You can easily find which part of speech or specific translation you will need to conjugate by first looking up the word and then pressing **CONJ**. Follow this example.

 Press MENU, use the arrow keys to highlight [FSP], and then press ENTER.

To choose English, highlight and press ENTER. You can also press CONJ and then LANG to choose the language.

- 2. Type a word (e.g., conocer).
- 3. Press ENTER to look it up.

```
conocer with the acquainted with a conocial Poet already met him?
2: to meet
3 reconocer: to recognize
conocerse wr
1: to know each other
conocerse bore conocerse wr
conocerse wr
conocerse wr
conocerse wr
conocerse wr
```

Read the definition to find the verb you want (e.g., to meet).

Press CONJ to conjugate the headword, conocer.

Highlight the translation you want (e.g., *meet*) and press **ENTER**.

```
OUERVIEW
yo conozco (today)
I meet (today)
yo conoceré (tomorrow)
I will meet (tomorrow)
yo conocí, yo conocía (yesterday)
I met, I was meeting (yesterday)
ay)
you was meeting (yesterday)
```

These are the principal forms of the Spanish verb "conocer". The English translations are below each Spanish inflection.

- Press SPACE or to scroll.Press ? to display the root word.
- Press CONJ or hold FN and press

   repeatedly to view more inflections.

If the word is a noun, an adjective, or another modifier, then there won't be any other inflections.

7. Press CLEAR when done.

#### ✓ Accenting Letters

You can look up accented words without typing accents. If there are no Multiple Forms, the dictionary will take you directly to the word. If there are Multiple Forms, you will have to choose the correct word from a Multiple Forms list. See "Choosing Multiple Forms" for more information. Remember, if you want to enter an accent yourself, type the letter and press (a) until the appropriate accent

appears. You can also hold **FN** and press  $\mathbf{n}$  to get an  $\tilde{n}$ .

#### ✓ Getting Grammar Guidance

When viewing inflections, you can press **HELP** to go directly to the Grammar Guide and view detailed descriptions of how to use the inflections you were viewing along with usage examples.

Press 🚯 to view this help message. UFRRS

A verb combines with a noun or pronoun used as the subject to express a thought. The form of the verb varies, depending on the time of the action:

CONJ LANG DICT LEARN GAMES

#### ✓ Viewing English Inflections

If you are unfamiliar with inflections, it may be helpful to look at some inflected forms of English verbs.

Switch the entry language back to English, type write, and press CONJ to

see the different forms of the English verb "to write".

```
OUERVIEW
I write (now/often)
yo escribo (now/often)
I wrote (in the past)
yo escribi (in the past)
I have writ or written (al-
ready/until now)
yo he escrito (already/until
cony lane Dior Learn Games
```

This will give you a good idea of each inflection form.

#### ✓ Verb Conjugations

The dictionary conjugates verbs into the following forms: present, imperfect, preterite, future, conditional, present subjunctive, imperfect subjunctive 2, present perfect, pluperfect, preterite anterior, future perfect, conditional perfect, present perfect subjunctive, pluperfect subjunctive, pluperfect subjunctive, pluperfect subjunctive 2, imperative, present progressive, and past progressive.

## Translating Travellers' Phrases

There are two ways in which you can translate several helpful phrases in categories ranging from *Emergencies* to *Business Communication* to *Time & Dates*. Note that the English phrase always appears before the Spanish phrase.

#### **Browsing Through Phrases**

- 1. Press MENU.


Press [] to view the Spanish phrases.



You can also hold **FN** and press ? to go straight to the Phrases menu in the same language as the lookup language.

 Press or to highlight the category you want and press ENTER.

Press ♠ or ♥ to highlight a subcategory, if needed, and press ENTER.



 Press or to highlight the phrase you want to translate and then press ENTER.



## Searching for a Specific Phrase

- Press CLEAR and then press LANG to select the look-up language, if needed.
- Type a keyword for which you'd like to find a phrase (e.g., ticket).
- 3. Hold FN and press ?.



### **Playing The Games**

You have seven fun games to choose from.

#### **Changing Game Settings**

Before you play, you can choose the source of the words, the skill level, the language, and whether or not graphics will be used.

- Press MENU, highlight and press ENTER.
- Hold down CAP and press to highlight Game Settings and press ENTER.



- 3. Use ♠ or ♥ to move ▶ to Words, Skill, Lang or Graphics. Words chooses the source of the words: All of them, TOEFL® List, My Word List, or Enter your own. Skill determines how easy or difficult a game is.
- Use or to change the setting(s) you want.
- 5. Press ENTER when done.

#### Selecting a Game

In the Games list, use (a) or (b) to move the highlight to the game of your choice and press **ENTER**.

#### Getting Help in the Games

During any game you can read instructions by pressing **HELP**.


You can get a hint by holding **CAP** and pressing ? or reveal the game word by pressing ?.

**Note**: If you reveal the game word, you lose the round.

### Using the Clock

The clock displays the current time and date. You can save two times: Home time and World time.

1. Press ORG.



Press **CLOCK** to toggle between Home time and World time.

- Press ENTER to set the time and date.
- 3. Use (a) o (7) to scroll through the options in the highlighted field.

- Use o to move to another field.
- Press ENTER when done.Press CLEAR to exit without saving the settings.
- Set the World time the same way you set the Home time.

### Using the Databank

#### Adding Entries

You can store as many as 100 names, telephone numbers, and addresses in the databank. The total number of names you can add depends on the size of each entry.

1. Press ORG and then press DATA.



- Highlight Add an Entry and then press ENTER.
- 3. Type a name and press ENTER.
- Type a phone number and press ENTER.

**Note: Q-P** will type numbers **0-9** automatically. To type a letter from this row, hold **FN** and press the letter key. To type a hyphen, hold **FN** and press **J**.

 Type a postal address or e-mail address and press ENTER.
 To type an @, hold FN and press

Μ.

#### Viewing or Editing Entries

- 1. Press ORG and then press DATA.
- Highlight View: XX entries (XX% free) and then press ENTER.
- To edit an entry, highlight it and press ENTER.

Type your changes. Use **③** to move the cursor; use **BACK** to delete.

Press ENTER to move to the number field.

Press **ENTER** twice to move to the address field.

Press ENTER again to save your changes or hold down FN and press BACK to cancel your changes.

#### **Deleting Entries**

- 1. Press ORG and then press DATA.
- 2. Highlight *Delete an Entry* and then press ENTER.

- 3. Highlight the entry you want to delete and press ENTER.
- To delete all databank entries, highlight Erase the List in the Databank Menu and then press ENTER.

Press Y to erase all databank entries or N to cancel the deletion.

#### **Using a Password**

You can use a password to prevent unauthorized access to the databank. **Warning!** Always write the password in a safe, separate location. If you lose or forget the password, you will be able to use the databank again only by removing the batteries from your BOOKMAN, which will permanently erase all the information stored in the databank.

- 1. Press ORG and then press DATA.
- 2. Highlight Set password and then press ENTER.



3. Type a password of up to eight characters and press ENTER.

Use (1) to move the cursor; use **BACK** to delete.

Press C to confirm or CLEAR to cancel the password.


The password you set will be requested the first time that the databank is used during a session.

To change the password, repeat Steps 1-4.

To remove a password, press **ENTER** at the blank password screen.

### Using the Calculator

1. Press ORG and then press CALC.



2. Type a number.

Note: Q-P will type numbers 0-9 automatically. You can type up to 10 digits. To type a decimal, press G (.). To change the sign of a number, press Z (+/-).


- 3. Press a math function key.
- 4. Type another number.
- Press ENTER. To repeat the calculation, press ENTER again.

lo Calculate	Press
reciprocals	FN + A
squares	FN + D
percentages	FN + F
square roots	FN + S
negative numbers	FN + Z

Press CLEAR to clear the current calculations.

#### **Using the Calculator Memory**

- 1. In the calculator, make a calculation or type a number.
- To add the number on the screen to the number stored in memory, press X (M+). To subtract the number on the screen from the number stored in memory, press C (M-).



**M** indicates the number is stored in memory.

- To retrieve the number from memory, press V (MR).
- To clear the memory, press B (MC).

## Using the Metric Converter

Press ORG and then press CONV.



- Use v to select a conversion category (e.g., Weights).
- Select a conversion (e.g., grams/ounces).
- 4. Type a number after one of the units.

  Note: *Q-P* will type numbers *0-9*automatically. Press ♠ or ♥ to move between the lines. Press

  BACK to delete a number
  - 5. Press ENTER to convert.
  - Press CLEAR to clear the current conversion.

# Using the Currency Converter

1. Press ORG and then press CURR.



2. Enter a conversion rate.

The rate should be in units of the other currency per one unit of the home currency (*n* other/1 home).

Enter an amount for the home or other currency.

Press 
or 
to move between the lines. Use **BACK** to delete a number.

- 4. Press ENTER to convert.
- Press CLEAR to clear the current conversion.

### **Installing Book Cards**

- Turn your product off and turn it over.
- Remove the blank protector or any other book card that might be installed.
- Align the tabs on the book card with the notches in the slot.



Press the book card down until it snaps into place. **Warning**: Never install or remove a book card while your product is on. Any information that was entered in the built-in book or book card will be erased.

### Selecting a Book

Once a book card is installed in the product, you can select which book you want to use.

- 1. Turn your product on.
- 2. Press CARD.



Icons appear for each available book.

3. Press (4) or (5) to highlight your selection.

- 4. Press ENTER to select it.
- Press CARD to return to the card menu.


#### ✓ BOOKMAN Card Troubleshooting

Make sure your book card is installed correctly. If your card is performing erratically, follow the reset instructions in "Resetting Your Product". If this does not fix the problem, remove the card and then remove the white rubber strip with your fingers and then replace it making sure it is completely in its notch.

## Using Function Keys in Book Cards

The function keys appear at the top of the keyboard on your unit. These keys correspond in the order listed to the dictionary and organizer keys at the bottom of the screen. The dictionary function keys change with the book card. The organizer function keys are unaffected. **Note**: Once you access the organizer from a book card, you will exit the book card. You must press **CARD** and select your book card to return to it.

The function keys on your unit correspond to the function keys on your card as illustrated below.



## Transferring Words Between Books

This dictionary can transfer words with certain other BOOKMAN book cards. To send a word to another book, you must first install a book card in your product, and that book card must be able to send or receive words. To learn if a book card can send or receive words, read its

1. Highlight a word in this dictionary.

To highlight a word in a dictionary entry, press **ENTER** to start the highlight, and use the arrow keys to move the highlight to the word you want.

- 2. Hold FN and press CARD.
  - Highlight the icon of the other book.

#### 4. Press ENTER.

The word you highlighted appears in the other book.

Press ENTER again, if needed, to search for that word.


### Resetting Your Product

If the keyboard fails to respond, or if the screen performs erratically, perform a system reset by following the steps below.

- Hold CLEAR and press .
   If nothing happens, try Step 2.
- Use a paper clip to gently press the reset button on your unit.

  The reset button is recessed in a

The reset button is recessed in a pin-sized hole below the book card slot.



Warning! Pressing the reset button with more than light pressure may permanently disable your product. In addition, resetting the product erases settings and information entered in its built-in book, and in an installed bookcard.

## Copyrights, Trademarks, and Patents

Model DBE-1470: Spanish <> English Dictionary/Diccionario inglés <> español

• Batteries: two AAA

• Size: 3 5/8 x 4 3/8 x 7/8 in or 9.2 x 11.1 x 2.2 cm

 Weight: 3.5 oz or 99.22 g (without batteries)

© 2002-2004 Franklin Electronic Publishers, Inc., Burlington, N.J. 08016-4907 U.S.A. All rights reserved.

© 1998 by Merriam-Webster, Incorporated. FCC Tested To Comply With FCC Standards

FOR HOME OR OFFICE USE.

U.S. Patents 4,830,618; 4,891,775; 5,113,340; 5,203,705; 5,218,536; 5,229,936; 5,295,070; 5,396,606; 5,497,474; 5,627,726; 5,895,463 ISBN 1-59074-262-1



This unit may change operating modes due to Electrostatic Discharge. Normal operation of this unit can be reestablished by pressing the reset key, **③**, or by removing/replacing batteries.

#### **FCC Notice**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## Limited Warranty (U.S. only)

LIMITED WARRANTY, DISCLAIMER OF WARRANTIES AND LIMITED REMEDY
(A) LIMITED WARRANTY. Franklin warrants to the original end user that for a period of one (1) year from the original date of purchase as evidenced by a copy of your receipt, your franklin product shall be free from defects in materials and workmanship. This limited warranty does not include damage due to acts of god, accident, misuse, abuse, negligence, modification, unsuitable environment or improper maintenance. The sole obligation and liability of franklin, and

your exclusive remedy under this limited warranty. will be repair or replacement with the same or an equivalent product of the defective portion of the product, at the sole option of franklin if it determines that the product was defective and the defects arose within the duration of the limited warranty. This remedy is your exclusive remedy for breach of this warranty. This warranty gives you certain rights: you may also have other legislated rights that may vary from jurisdiction to jurisdiction. (B) DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY. Except for the limited warranties expressly recited above, this franklin is provided on an "as is" basis, without any other warranties or conditions, express or implied, including, but not limited to, warranties of merchantable quality, merchantability or fitness for a particular purpose, or those arising by law, statute, usage of trade, or course of dealing. This warranty applies only to products manufactured by franklin and does not include batteries. corrosion of battery contacts or any other damage caused by batteries. Neither franklin nor our dealers or suppliers shall have any liability to you or any other person or entity for any indirect, incidental, special, or consequential damages whatsoever, including, but not limited to, loss of revenue or profit, lost or damaged data or other commercial or economic loss, even if we have been advised of the possibility of such damages,

or they are otherwise foreseeable. We are also not responsible for claims by a third party. Our maximum aggregate liability to you, and that of our dealers and suppliers, shall not exceed the amount paid by you for the franklin product as evidenced by your purchase receipt. You acknowledge that this is a reasonable allocation of risk. Some states/countries do not allow the exclusion or limitation of liability for consequential or incidental damages, so the above limitation may not apply to you. If the laws of the relevant jurisdiction do not permit full waiver of implied warranties, then the duration of implied warranties and conditions are limited to the duration of the express warranty granted herein.

(C) WARRANTY SERVICE: Upon discovering a defect, you must call franklin's customer service desk, 1-800-266-5626, to request a return merchandise authorization ("rma") number, before returning the product (transportation charges prepaid) to:

FRANKLIN ELECTRONIC PUBLISHERS, INC. ATTN: SERVICE DEPARTMENT ONE FRANKLIN PLAZA

BURLINGTON, NJ 08016-4907

If you return a franklin product, please include a note with the rma, your name, address, telephone number, a brief description of the defect and a copy of your sales receipt as proof of your original date of purchase. You must also write the rma

prominently on the package if you return the product, otherwise there may be a lengthy delay in the processing of your return. We strongly recommend using a trackable form of delivery to franklin for your return.

# Limited Warranty (EU and Switzerland)

This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin for a period of two years from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the European Union and Switzerland that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

# Limited Warranty (outside U.S., EU and Switzerland)

This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the United States, the European Union and Switzerland that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

LPB-28002-00 Rev D

Rev. L